



CANBUILT MFG.

www.canbuilt.com

March 2022


CRANE OPTIONS



Model # 5280 Crane Base Counter Balance


The addition of counterbalance provides the ability to lift where the lift point of the crane is extended past the front wheels. Ideal for low clearance vehicles when legs are removed and installed from the rear of the crane.

Available as a single counterbalance unit or multiples in-line or stacked. Fit onto crane base behind upright mast or on legs telescoped back. Available as 100lb+ units.



Model # 3200SSL Skid Spread Adapter

Skid Spread Adapter, slips into base of 4200/ 3900, legs install into adapter and provides a 48" clear space between the legs, enabling the crane to straddle and safely lift from the middle of a standard 42- 44" skid.



OPTION ONLY FOR 4200

Model # 3275 Mast Height Adapter

Mast height Adapter, slips into mast of 4200, to provide 12" more horizontal mast height which allows insertion of boom at correct entry angle into engine compartment of larger vehicles.

Model # 3276 Additional Mast Height Adapter

Combines with 3275 to provide 24" of additional horizontal mast height



103 Milvan Drive, Toronto, Ontario, Canada, M9L 1Z7

Toll-Free in Canada: 1-888-607-2926 Phone: 416-749-6555 Fax: 416-749-7597 Email: sales@canbuilt.com