


CANBUILT MFG.

Foll-Free in Canada: 1-888-607-2926 Phone: 416-749-6555 Fax: 416-749-759.
Email: sales@canbuilt.com Website: www.canbuilt.com

103 Milvan Drive, Toronto, Ontario, Canada, M9L 1Z7

2 TON MOBILE CRANE



Skid Spread Adapter, slips into base of all Canbuilt cranes except 4400P, legs install into adapter and provides a 48" clear space between the legs, enabling the crane to straddle and safely lift from the middle of a standard 42- 44" skid.

Model # 3200SSL

Skid Spread Adapter

Crane Base Counter Balance

Counterbalance allows lifting when the lift point is extended past the front wheels or when dealing with low clearance vehicles where crane legs can't slide under. Then, legs are removed and installed from the rear and crane can moved right up to the vehicle to perform the lift.

Available 100 Lbs counterbalance units. Fits behind upright mast. Put them in line or stack them up for more weight.